

NEW PRODUCT FOR 2007



63014

Billet Aluminum Reservoir Clamps

These clamps are machined from 6061 billet aluminum and feature a finned design that helps dissipate heat transferred from the shocks' remote reservoir. Stainless steel, threaded inserts prevent the bolt from stripping threads or cross threading in these hot looking, cool operation aluminum clamps. Five sizes available to fit any 2" diameter or MX6 Reservoir to the shock body or to a 1.5" diameter shock hoop. Clear anodized. Sold in pairs, one pair required per shock.

Part No.	Description
63014	Aluminum clamp set: Pro Comp 2" shock to 2" shock
63015	Aluminum clamp set: Pro Comp 2" shock to 1.5" hoop tube
63016	Aluminum clamp set: Pro Comp MX6R to MX6R body
63017	Aluminum clamp set: Pro Comp MX6R to 1.5" hoop tube
63018	Aluminum clamp set: Pro Comp MX2.75CR to 1.5" hoop tube

Note: Package contains two clamps.



Stainless steel, threaded inserts prevent the bolt from stripping threads



Finned aluminum design helps dissipate heat transferred from the remote reservoir

Poly Lift Kits

So you're on a budget but you want to fit a larger tire on your rig? No worries! Pro Comp Suspension's new Poly Lift Kits are just what you need.

The heart of each lift kit incorporates a precision computer aided designed coil spacer molded from a proprietary polyurethane formulation that provides a firm yet supple ride without sacrificing articulation on and off-road. These kits utilize the stock coil springs and come with all the necessary hardware. In order to maximize performance and ride quality, we highly recommend you replace your existing shocks with Pro Comp Suspension's performance ES Series shocks or our premium MX6 six-way adjustable shocks.

Year	Application	Part Number	Description
05-07	Ford F250, F350 Super Duty 4WD	64202	Front 2 1/2" Lift Spacer Kit (2)
04-07	Ford F-150 2WD & 4WD	64201	Front 2 1/2" Lift Spacer Kit
94-07	Dodge Ram 2500-3500 4WD	64401	Front 2" Lift Spacer Kit (1)
94-01	Dodge Ram 1500 4WD	64401	Front 2" Lift Spacer Kit (1)
05-06	Toyota Tacoma	64302	Front 2 1/2" Lift Spacer Kit
96-04	Toyota Tacoma/Tundra	64301	Front 2 1/2" Lift Spacer Kit
96-02	Toyota 4Runner	64301	Front 2 1/2" Lift Spacer Kit
05-06	Jeep KJ Liberty	64102	Front and Rear 1 1/2" Lift Spacer Kit
05-06	Jeep WK Grand Cherokee	64103	Front and Rear 2" Lift Spacer Kit
97-06	Jeep TJ Wrangler/Rubicon/Unlimited	64101	Front or Rear 1 3/4" Lift Spacer Kit (3)
2007	Jeep JK Wrangler	64105	Front and Rear 1 3/4" Lift Spacer Kit
99-04	Jeep WJ Grand Cherokee	64104	Front and Rear 2" Lift Spacer Kit
04-06	Nissan Titan/Armada 2WD & 4WD	64501	Front 2 1/2" Lift Spacer Kit
05-06	Nissan Xterra	64502	Front 2" Lift Spacer Kit

1) Not recommended with off road package (2) Longer shocks recommended (3) Buy two kits for front and rear



64202



64401



64101

